


ORO.2691 | Thermostatic Wall Mounted Bathtub Filler With Hand Shower



ORO.2691 Includes Valve [JVH.2691] + Trim [ORO.2691T**]


SPECIFICATIONS:

- Wall Mount Tub Filler
- Spout Projection = 9"
- Turn center knob to set temperature
- Turn right knob to activate output 1 - Hand Shower
- Turn left knob to activate output 2 - Tub Spout
- Thermostatic Valve Flow Rate - 22 LPM @ 3 BAR
- Hand Shower & Tub Spout positions can be swapped




See Spec Sheet For
JVH.2691 For Detailed
Information On Valve.

Technical Diagram




JVH.2691 | 3/4" Thermostatic Wall Mount Tub Filler Valve - 2 Outputs Page 1 of 2



SPECIFICATIONS:

- Wall Mount Tub Filler
- Turn center knob to set temperature
- Turn right knob to activate output 1 - Hand Shower
- Turn left knob to activate output 2 - Tub Spout
- Thermostatic Valve Flow Rate - 22 LPM @ 3 BAR

Technical Diagram



JVH.2691 | 3/4" Thermostatic Wall Mount Tub Filler Valve - 2 Outputs Page 1 of 2

Water Diversion Diagram

