



- Wall Mount Tub Filler Trim
- Valve not included - Trim only
- Spout Projection = 9"
- Turn center handle to set temperature
- Turn right handle to activate output 1 - Hand Shower
- Turn left handle to activate output 2 - Tub Spout
- Hand Shower & Tub Spout positions can be swapped

