



RHE.7000 | Single Output Shower Se W/ Rain Shower



COMPONENTS

- HH1050 - 15" Shower Arm
- RHB.10C - 10" Shower Head
- RHE.4101T - Shower Trim
- JVH.4101 - 3/4" Shower Valve

SHOWER VALVE:

- Thermostatic shower valve
- Valve includes service stops
- Turn bottom handle to set temp.
- Top handle controls water volume

SHOWER HEAD:


- Solid brass construction
- 11 LPM flow rate

See individual component specification sheets on following pages for further details.


HH1050 | Square Shower Arm - 15"

SPECIFICATIONS:


- Solid Brass Shower Arm
- With Fixed Flange



Technical Diagram





RHB.10C | 10" Brass Rain Shower




SPECIFICATIONS:

- Solid Brass Shower Head
- Scrub rubber nozzles to easily clean water sediment
- 11 LPM Flow Rate
- 200 Nozzles
- Use with HH1050 Shower Arm

Technical Diagram




RHE.4000T | Thermostatic Shower Trim



SPECIFICATIONS:

- Solid Brass construction
- Valve not included - trim only
- Turn bottom handle to control temperature.
- Turn top handle to divert water & control volume
- Extension Available - JVH.4101E**


Technical Diagram




JVH.4101 | 3/4" Thermostatic Valve With Volume Control Page 1 of 2

SPECIFICATIONS:

- Turn bottom knob to control temperature.
- Turn top knob to control water flow.
- Thermostatic Valve Flow Rate - 36 LPM @ 3 BAR
- Extension Available - JVH.4101E**



Technical Diagram



JVH.4101 | 3/4" Thermostatic Valve With Volume Control Page 2 of 2

Water Flow Diagram

