


### RHE.7050 | Two Output Shower W/ Rain Head & Hand Held




See individual component specification sheets on following pages for further details.




# HH1050 | Square Shower Arm - 15"

### SPECIFICATIONS:



- Solid Brass Shower Arm
- With Fixed Flange








# RHB.10C | 10" Brass Rain Shower

#### SPECIFICATIONS:

- Solid Brass Shower Head
- Scrub rubber nozzles to easily clean water sediment
- 11 LPM Flow Rate
- 200 Nozzles
- Use with HH1050 Shower Arm











Rheo™

# RHE.4000T | Thermostatic Shower Trim



### SPECIFICATIONS:

- Solid Brass construction
- Valve not included trim only
- Turn bottom handle to control temperature.
- Turn top handle to divert water & control volume
- Extension Available JVH.4101E\*\*






# JVH.4420F | 3/4" Thermostatic Mixer Valve - 2 Output Page 1 of 2

### SPECIFICATIONS:

- Turn bottom knob to control temperature.
- Turn top knob to control water flow.
- Thermostatic Valve Flow Rate 22 LPM @ 3 BAR
- Extension Available JVH.4101E\*\*







# JVH.4420F | 3/4" Thermostatic Mixer Valve - 2 Output Page 2 of 2

### **TWO OUPTUT - NO SHARED PORT OPERATION**

Diverter Cartridge # - **15109** (Included)

Total 3 Positions as defined below, with **only** 1 port active at one time.


- Position 0 Off No Water Flow
- Position 1 Output B Activated
- Position 2 Output C Activated

#### **TWO OUPTUT - SHARED PORT OPERATION**


Diverter Cartridge # - **15103** (Not Included)

Total 4 Positions as defined below, with 2 ports active at one time.

- Position 0 Off No Water Flow
- Position 1 Output B Activated
- Position 2 Output B+C Activated
- Position 3 Output C Activated



#### Water Diversion Diagram



Diverter Position = 1

- Diverter Position = 2
- Diverter Position = off



# HH1003 | Solid Brass Hand Shower Set

